

# INSTALLATION INSTRUCTIONS FOR WASHIE TOILET SEAT

IMPORTANT! FOR SECURE MOUNTING, FOLLOW INSTRUCTIONS THOROUGHLY. PLEASE SCAN QR CODE FOR INSTRUCTIONAL VIDEOS.

SCAN



## INCLUDED IN THIS BOX:

- WASHIE TOILET SEAT
- NUT (2), FLAT WASHER (2), LOCK WASHER (2)
- EXTENTION
- BATTERY PACK
- BATTERY CHARGING CORD
- COMPARTMENT KEY
- 3 STEP INSTRUCTION STICKER

## TOOLS NEEDED:

- 13 mm - 2.5" ratchet
- For effortless installation please use the Flexible head 13 mm ratchet wrench.



## INSTALLING WASHIE TOILET SEAT

- Align the extension attached to the seat and mount seat on toilet bowl.
- Insert bolts through bolt holes.
- Add flat washer, lock washer and nut to bolt on underside of bowl.
- Secure nut using 13mm - 2.5" ratchet wrench.



## INSTALLING CARTRIDGE

PLEASE SCAN QR CODE FOR INSTRUCTIONAL VIDEOS.

SCAN



- Open cartridge door using compartment door key.
- Prime the cartridge - Face the cartridge into the toilet bowl. Press down on the cartridge pump several times until foam exits the nozzle.
- Insert cartridge in seat with “THIS SIDE UP” facing upwards.
- Lock cartridge into place by turning cartridge lock to the left.
- If seat is already powered ON, seat will beep once when new cartridge is installed.



- When cartridge is low, the seat will beep once every 60 seconds.
- Each cartridge holds 2000 uses and is 100% recyclable.
- Once a cartridge is empty, remove used cartridge and recycle appropriately.

## INSTALLING BATTERY

PLEASE SCAN QR CODE FOR INSTRUCTIONAL VIDEOS.

SCAN



- Open battery door using compartment door key.
- Insert battery with “THIS SIDE UP” facing upward.
- Battery will *click* when properly inserted.
- Turn device ON using ON/OFF switch, seat will beep once.
- Replace battery door and lock using compartment key.



- When the battery is low, the seat will beep twice every 60 seconds.
- Batteries can keep a charge for 60-90 days depending on restroom traffic.
- The battery will need to charge for approximately 8 hours. A green light on the charging cord will indicate that the battery is fully charged.
- Please unplug from charging cord (D) as soon as it is done charging DO NOT OVERCHARGE.
- When needed, dispose of lithium-ion battery according to local battery disposal regulations.

# INSTALLING STICKERS

PLEASE SCAN QR CODE FOR INSTRUCTIONAL VIDEOS.

SCAN



- Peel and stick the instruction sticker directly above the toilet on wall.
- If you have received a QR Code Survey Sticker, please peel and place sticker on the back of stall door.
- Please do NOT stick stall sticker directly under a coat hanger where it can be blocked from view.

## 3-STEP INSTRUCTION STICKER



## QR CODE SURVEY STICKER

